

Inside Micrometers

Tubular Inside Micrometers
SERIES 139 — Extension-Pipe Type (main unit)

- Micrometer head for Extension-pipe Type inside micrometer.
- A reference gage is necessary for reference point setting.
- An optional reference gage, such as Gauge Block Accessory Set, CERA Inside Micro Checker or a setting ring, is required for accurately setting the micrometer before measuring. (refer to pages 01-19 to 01-22, 08-30, and 08-53 for details)



139-001

SPECIFICATIONS

Metric				
Code No.	Range (mm)	Spindle feed error* (μm)	Graduation (mm)	Micrometer head stroke (mm)
139-001	100 - 125	3	0.01	25

Inch				
Code No.	Range (in)	Spindle feed error* (in)	Graduation (in)	Micrometer head stroke (in)
139-002	4 - 5	0.00015	0.001	1

* "Spindle feed error" refers to the difference between the maximum and minimum indication error values within the specification range of the micrometer head

DIMENSIONS

